


# Overhead Door™ And Genie™

## Learn Code Button Programming

*Ops. manufactured  
1993-2011*



- 1) Locate the Learn Code button and learn indicator on the power head.

(Remove lens cover on back of power head.)



- 2) Press and Release the learn code button on power head.

(LED on motor will blink 2 times per second)



- 3) Press and release a remote control button, (LED on motor will stop blinking and turn solid)



- 4) Press and release the same remote control button again.

(LED light will go out.)



- 5) Press and release the same button again and the door will run. Your remote is now programmed!




*Learn Code on motor once, remote twice. Third time door will run.*





## Program Set Button Programming

*Ops. manufactured  
2011-current*





Press and hold the  
Program Set button  
(The round LED turns blue)

Release the  
Program Set button  
(The long LED will flash purple)



Press and release the button you  
have chosen on the remote  
(Long LED comes on purple)

Press and release the same  
button on the remote  
(Both LED's flash blue, then turn off)



Press and release the same  
button on the remote  
(Door should open or close)

